

## Lab 2: Setting Up a Local Area Network (LAN) with a Switch

Name: JAISREE N

REG NO: RA2211003050151

Aim: Configure a LAN using a switch and multiple PCs to understand basic networking and connectivity within a LAN.

Objectives:

1. Connect multiple PCs to a switch.
2. Assign IP addresses to each PC.
3. Test network connectivity between PCs using the ping command.

Steps:

1. Open Cisco Packet Tracer:

- Launch Cisco Packet Tracer and create a new project.

2. Add Devices:

- Add a Switch: Drag a switch (e.g., 2960) from the "Switches" category to the workspace.
- Add PCs: Drag multiple PCs (e.g., PC0, PC1, PC2) from the "End Devices" category to the workspace.

3. Connect PCs to Switch:

- Copper Straight-Through Cable Use a copper straight-through cable to connect each PC's Fast Ethernet 0 port to one of the switch ports.
  - Color Codes for Copper Straight-Through Cable (TIA/EIA-568B Standard):
    - Pin 1: White/Orange
    - Pin 2: Orange
    - Pin 3: White/Green
    - Pin 4: Blue

- Pin5:White/Blue
- Pin6:Green
- Pin7:White/Brown
- Pin8:Brown

4. Assign IP Addresses:

○ Configure Each PC:

■ Click on a PC, go to the Desktop tab, and open IP Configuration.

■ Assign IP addresses in the same subnet (e.g., PC0: 192.168.1.2, PC1: 192.168.1.3, PC2: 192.168.1.4) with a Subnet Mask of 255.255.255.0.

5. Test Connectivity:

○ On each PC, use the Command Prompt to ping the other PCs to verify connectivity.